
# Using Hit Air

### 5-1 One-touch Release

Connect the male connector at the end of the coiled wire attached to the saddle with the female connector attached to the key ball in the key box.



CAUTION 1




Hold the female connector and insert the male one. A clicking sound confirms that a connection has been made. Pull the male connector lightly to make sure that the connection has been made properly.

CAUTION 2. If you have difficulty making the connection, clean the male and female parts thoroughly.

CAUTION 3. Change it for a new one, if the insertion cannot be made properly.

Insertion by force may cause a malfunction of the one-touch release.



Coiled wire



Easy to adjust its length with the belt and easy to attach to the right place.

Buy an additional coiled wire/bungee lanyard for each additional saddle.

### 4-3 Key Box (Y-type)

With a tensile strength of approximately 30kg-35kg by the "coiled wire", the "key ball" comes out of the "key box". Then a needle in the "key box" is activated and punctures the seal of the gas cartridge to inflate the Hit Air instantly.

The "key ball" can be pulled out from any direction (Photo 1).

## CAUTION

1. Do not take the "key box" a part or remove any part.

#### CAUTION

Screw in the gas cartridge fully until it seats firmly but do not over tighten. If anything wrong, consult with an authorized dealer.

