



hit-air

SHOCK BUFFERING SYSTEM

Horse Riding



Hit-air airbag instantly inflates when a rider is thrown from the horse .

hit-air airbag system

Wearable airbag

Hit-air airbag structure

Key box
holds a CO2 gas cartridge.

Key ball to be pulled out
to release the gas into the
airbag instantly.

Coiled wire to be
connected to the center
of the saddle holder



One-touch release
to connect/disconnect a coiled wire
when getting on/off the horse.

CO2 gas released from the gas cartridge
inflates the urethane airbag instantly.

Neck airbag

Chest airbag

Back airbag

Sides airbag

Hip airbag

※Design and shape of jacket may vary.

Airbag inner system (After)



An inflated airbag protects your neck, back, chest, sides and hip firmly.

MUGEN
DENKO JAPAN

MUGEN DENKO CO.,LTD.

www.hit-air.com/horse

hit-air
SHOCK BUFFERING SYSTEM